

Thank you for your purchase of the Adtec DPI-1200 Ad Server.

The most recent firmware releases are available on our support website, [www.adtecdigital.com](http://www.adtecdigital.com). Advanced users can find direct API command help as part of the on-board web application, Help Tab.

### Channels 1 - 12

- Not Active
- Channel Connected
- Pre-Roll / Transitioning
- Channel Disconnected

### High Availability:

Each channel is individually configurable for ASI or IP Streaming.

3 x Mirrored ASI ports allows for connection of up-to 3 separate splicers.

IP streaming via Unicast or Multicast using the GigE Connection.

**\*Note:** If the same Multicast or Unicast address for multiple channels, the Multicast Port will need to be incremented by 2 for each channel.

Example: Channel 1 = Port 2000  
Channel 2 = Port 2002

### Reset:

Should you need to reset your device, you can do so via the front panel by pressing the MODE, ESCAPE and RIGHT ARROW keys simultaneously.

### System LED Status

#### Power

- Power is OFF
- Power is ON

#### Alarm

- No System Alarm
- Minor Alarm
- Major Alarm

#### Link

- No Link Detected
- Link Active

#### Busy

- No Network Traffic
- Network Traffic Present

| System      | NetSet         | Splicer        | Cue              |
|-------------|----------------|----------------|------------------|
| Login       | <<CH1 - CH12>> | <<CH1 - CH12>> | <<CH1 - CH12>>   |
| Network     | Mode           | Mode           | DTMF History     |
| Time        | Days On        | Name           | DTMF Newest      |
| NTP         | Type           | Splicer IPA    | DTMF Oldest      |
| Alarm       | Start          | Splicer Name   | GPI State        |
| Mirror      | Stop           | Chassis        | GPI Time Changed |
| RAID Status | Pre-Roll       | Card           | GPO State        |
| Name        | Post-Roll      | Port           | DTMF Speaker     |
| Firmware    | Avail          | Lead In        |                  |
|             | End By         | Schedule ID    |                  |
|             |                | Format         |                  |
|             |                | Break Repeat   |                  |
|             |                | Multicast IPA  |                  |
|             |                | Multicast Port |                  |

### Front Panel Menus:

**MODE** Use Mode Button to move through top layer menus.



Use arrows for navigation in submenus.

**SELECT** Use select to enter into edit mode and **ENTER** enter to save selection.

Units ship with the front panel logged in by default. If you become logged out and are prompted for a password, use the following key sequence for access.

Press <Select> when panel displays **'User Login -- logged out'**

Press <Up arrow>  
Press <Select>  
Press <Enter>  
Press <Right arrow>  
Press <Enter>



