

RD-70

**10-bit / Multi-CODEC 1080P
Receiver / Decoder**

Includes demodulator versions - ADV, LB and PRM

USER GUIDE

v2.02.24



Contents

[Contents](#)

[Trademarks & Copyrights](#)

[Electrical Device Compliance Notices](#)

[Safety Warnings and Cautions](#)

[Compliance Notices](#)

[FCC](#)

[Industry Canada](#)

[European Union EMC Directive Conformance Statement](#)

[Chapter 1 - Product Introduction](#)

[Front Panel](#)

[Front Panel LCD](#)

[Transport LED Indicators](#)

[Audio Decode Indicators](#)

[System Indicators](#)

[Controls](#)

[Reset](#)

[Front Panel Menu Structure](#)

[Services Menu](#)

[RF Rx Menu \(ADV Advanced / PRM Premium\)](#)

[RF Rx Menu \(LB L-Band\)](#)

[IP Rx Menu](#)

[Video Menu](#)

[Audio Menu](#)

[VBI Menu](#)

[CAS Menu](#)

[System Menu](#)

[Login](#)

[Duration](#)

[Com2](#)

[Host Name](#)

[Firmware](#)

[Feature Menu](#)

[Profile Menu](#)

[Back Panel](#)

[DB9-M Analog audio output pinout](#)

[COM1/COM2 to DB9 Serial Adapter](#)

[GPIO and Parport information](#)

[GPIO Pinout](#)

[Parport Pinout](#)

[Chapter 2 - Getting Connected](#)

[Introduction to the Control Application](#)

[Compatible browsers](#)

[Ethernet Access](#)

[Zero Configuration Access](#)

[Login](#)

[Chapter 3 - Operational Information](#)

[DVB-S / DVB-S2 AUTO Modes \(ADV and PRM option\)](#)

[DVB-S / DVB-S2 AUTO Modes \(LB option\)](#)

[DVB-S2 - Recommended use of Pilots](#)

[How to use RF Profiles \(LB option\)](#)

[UDP / RTP / FEC / TCP IP Rx](#)

[Multicast Reception - Address](#)

[Unicast Reception - Address](#)

[Unicast/Multicast Reception](#)

[Dolby E, Dolby D, LPCM, and Mpeg 1 Layer 2](#)

[AFD - Active Format Description](#)

[Genlock System](#)

[TS Out Decrypt](#)

[Service Filtering](#)

[Configure Service Filter on ASI](#)

[Firmware Upgrade via Web User Interface](#)

[Demodulator Firmware Upgrade via Web User Interface](#)

[Upgrading via FTP & Telnet](#)

[In Field Feature Upgrades](#)

[Permanent Key Instructions](#)

[Temporary Key Instructions](#)

[Feature Key Descriptions](#)

[Chapter 4 - Appendix](#)

[Appendix A - GNU General Public License](#)

[Appendix B - Technical Specifications](#)

[Base Model \(RD70-XX\)](#)

[Inputs](#)

[Outputs](#)

[Communications](#)

[Video and Audio](#)

[Physical and Operational](#)

[Advanced Demodulator \(ADV option\)](#)

[L-Band Demodulator \(LB option\)](#)

Premium Demodulator (PRM option)

Appendix C - Adtec Digital Support & Service

Trademarks & Copyrights

Copyright: (c) 2011-15 Adtec Digital. All rights reserved. This document may not, in whole or in part, be copied, photocopied, reproduced and translated, or reduced to any electronic medium or machine-readable form without prior written consent from Adtec Digital.

Trademarks: RD-70 is a trademark of Adtec Digital. Dolby, Dolby Digital, AC-3 and the double-D symbol are registered trademarks of Dolby Laboratories. Other product and company names may be trademarks or registered trademarks of their respective companies. The information in this document is subject to change without notice.

Electrical Device Compliance Notices

Safety Warnings and Cautions

For your safety and the proper operation of the device:

- This unit must be installed and serviced by suitably qualified personnel only.
- Do not break the warranty seals on the device or open the lid. Only approved service technicians are permitted to service this equipment.
- Disconnect all power before servicing the unit.
- Do not expose this device to rain or other moisture. Clean only with a dry cloth.
- If not installed in an equipment rack, install the product securely on a stable surface.
- Install the product in a protected location where no one can step or trip over the supply cord, and where the supply cord will not be damaged.
- If a system is installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than the room ambient temperature.
- Consideration should be given to installing the unit in an environment compatible with the maximum recommended ambient temperature of 50 degrees Celsius (122 degrees Fahrenheit).
- Install the unit in a rack so that the amount of airflow required for safe operation is not compromised.
 - The recommended clearance on the top and sides of the unit is at least ½ " (one half inch/one centimeter).
- Mounting of the unit in a rack should be such that no hazardous condition is achieved due to uneven mechanical loading.
- Use only a grounded electrical outlet when connecting the unit to a power source.
- Reliable earth grounding of rack-mount equipment should be maintained.
 - Particular attention should be given to supply connection other than direct connections to the branch circuit (e.g., use of power strips).

Compliance Notices

FCC

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this device not expressly approved by Adtec Digital could void the user's authority to operate the equipment.

Industry Canada

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareillage numérique de la classe B répond à toutes les exigences de l'interférence canadienne causant des règlements d'équipement. L'opération est sujette aux deux conditions suivantes: (1) ce dispositif peut ne pas causer l'interférence nocive, et (2) ce dispositif doit accepter n'importe quelle interférence reçue, y compris l'interférence qui peut causer l'opération peu désirée.

European Union EMC Directive Conformance Statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. Adtec Digital cannot accept responsibility for any failure to satisfy the protection requirements resulting from a user modification of the product. This product has been tested and found to comply with the limits for Class B Information Technology Equipment according to CISPR 22 / EN 55022.

Chapter 1 - Product Introduction

Front Panel

The front panel LCD and keypad can be used to configure and monitor your device.



Model Indicators:

- Premium demodulator
- Advanced demodulator
- LB demodulator
- No demodulator

Front Panel LCD

1) Feedback State: There are several quick view menu screens available when in regular feedback state. You can view any of these quick view status screens by using the up and down arrow buttons.

Decoder Activity	TMR	Encryption
DECODING ASI	TMR:20.000M	CAS:Free to Air
SVC: 00001	"Service Name"	Service Provider
Service ID	Service Name	Service Provider
Video PID	PCR PID	CODEC
VID: 481	PCR:481	COD: H.264
VRT: 18.012M	RES:1920X1080	FR:59i CHR: 422
Video Rate	Resolution	Frame Rate
		Chroma
Audio 1-8	Type	Bitrate
1:MU 384k	2:MU 384k	3:MU 384k
4:MU 384k	5:MU 384k	6:MU 384k
7:MU 384k	8:MU 384k	
Audio PIDS 1- 8		
Audio 1:11300	2:11400	3:11500
PIDS 5:11300	6:11400	7:11500
		8:11600
Input	Mode/FEC	Rcv Level
RF1	32APSK9/10	Lvl: -52.0dB LMar:20.5dB
Locked	DVB-S2	Sym:29.970Ms Eb/No:29.8dB
Lock Status	Type	Symbol Rate
		Eb(s)/No
RTP Detected	RTP Error Count	Buffer
RTP: Y	RTP-Err: 1234567	Buffer:1234ms
FEC: Y	FecLoss: 1234567	FecCorr: 1234567
FEC Detected	FEC Packet Loss	FEC Corrections

2) Disabled Product State: When the product is in a disabled state, the LCD will relay the

following information. This state is generally only used when a factory restore is performed. If that is the case, note that all of the configurations have been returned to factory defaults including Network configurations. To reapply network configurations simply press the Down arrow when in this state to navigate through the network menu.



Transport LED Indicators

Indicator	Function
Decode	Off - Decoder is idle. On - Decoder is active.
ASI / IP /RF	Off - No services detected on the input. On - Services detected on the input.
Lock 1 / Lock 2	Off - Tuner is not locked On - Tuner is locked
IP Out	Off - IP Egress is idle. On - IP Egress is active.
Bars	Off - All B/T/ID options are disabled. On - B/T/ID options are enabled.

Audio Decode Indicators

Indicator	Function
A1 through A8	Off - Audio engine is not active. On - Audio engine is actively decoding or performing passthru. Blinking - Audio engine is in a failure mode (no passthru or audio decoding)

System Indicators

Indicator	Function
Alarm	Off - No system alarms. On - System alarm. (NTP or FAN alarm)
BISS	Off - Decryption configuration is turned OFF On - Decryption configuration is set to BISS1 or BISSE
Link	Off - Network communication link not detected On - Network communication link detected
Busy	Off - No network activity On - Network traffic present

Controls

Using the **Mode**, **Select**, **Enter**, **Escape**, and directional buttons, the user can control the unit via the front panel.

Control	Function
Mode button	Mode will cycle through top layer menus.
Select	Select will enter into edit mode.
Enter	Enter submits any edited configurations.
Escape	Escape returns to the previous menu layer.
Cursor Arrows	Arrows will navigate you within submenus
Programming Keypad	For value entry. F1 functions as a "+" or "-" operator. F2 functions as a "." decimal or period.

Reset

Should you need to reset your device, you can do so via the front panel by pressing the MODE, ESCAPE and RIGHT ARROW keys simultaneously.

Front Panel Menu Structure

Services Menu

Item	Function	Options
List of Services	Allows selection of a service from a list of services per input.	ALL ASI RF1 RF2 IP
Decode First Found	Allows you to configure the RD-70 to decode the first valid program found on any input.	ASI RF1 RF2 IP

RF Rx Menu (ADV Advanced / PRM Premium)

Item	Function	Options
Select Tuner*	Selects RF1 or RF2 as the RF acquisition source	RF1 RF2
Local Oscillator	The Local Oscillator (L.O.) control specifies the frequency of the LNB local oscillator. The standard L.O. frequencies for "C" and "Ku" bands are 5150MHz and 10750MHz respectfully although, some other variants are included. If the desired L.O. frequency is not listed, select either C: Manual or Ku: Manual and enter the L.O. frequency in the Manual L.O. field.	C: 5150 KU: 11300 KU: 10750 KU: 10600 KU: 10000 KU: 9750 KU: 9600 C: MANUAL KU: MANUAL
Manual LO	Allows manual entry of the LNB Local Oscillator frequency provided that either C: Manual or Ku: Manual is selected from the Local Oscillator pulldown menu.	
Downlink	Allows the operator to enter the satellite downlink frequency. The value for the Downlink frequency is used with the Local Oscillator frequency to calculate the L-Band frequency. The Downlink and Local Oscillator frequencies can be used to determine if spectrum inversion occurs using the following rules. If the Downlink frequency is less than the Local Oscillator frequency, then spectrum inversion does occur. If the Downlink frequency is greater than the Local Oscillator frequency, then spectrum inversion does not occur.	Range dependent upon LO configuration
L-Band	Allows the operator to enter the L-Band frequency within the range from 950MHz to	950MHz - 2150MHz

	2.15GHz. The value entered in this field is used with the Local Oscillator frequency to calculate the Downlink frequency using the following rules. If Downlink < Local Oscillator, then Downlink - Local Oscillator = L-Band . If Downlink > Local Oscillator, then Downlink - Local Oscillator = L-Band	
Modulation Type	Allows the selection of the mod type.	DVBS DVBS-2
CCM Mode*	<p>When the Constant Coding and Modulation (CCM) option is selected, the same modulation mode and FEC is used for all physical layer framing. The advantage of using DVB-S2 in the CCM mode is the improved protection that is achieved by utilizing the new inner and outer codes. Another advantage is the 30 percent increase in capacity that is realized while using the method. If Auto-CCM is selected, the receiver will detect and configure the Modulation Mode, Pilot, and Frame Type.</p> <p>Adaptive Coding and Modulation (ACM) is available for receivers with the appropriate hardware and feature key. In this mode, modulation and coding can vary on a DVB-S2 frame by frame basis. Auto-CCM is the preferred method to automatically detect modcod, pilots and frame type. **This configuration is not available via front panel at this time.</p> <p>note: this field is not applicable for DVB-S. Similar functionality (AUTO MODCOD detection) can be used in DVB-S by using QPSK_AUTO or 8PSK_AUTO modulation modes.</p>	CCM AUTO-CCM
Modulation Mode	<p>This control allows the operator to select the desired modulation mode and FEC code rate.</p> <p>note: This is a configuration value. When in DVB-S2 AUTO-CCM mode, actual detected modulation can be found in the Quick View status. QPSK_AUTO and 8PSK_AUTO configurations are only valid in DVB-S. See how to appendix for automatic detection instructions.</p>	We display all possible ranges available via our device in the Front Panel. This list will differ from the list found in the web UI as it only shows those options available based on the hardware and feature keys found.

		QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 QPSK_AUTO* 8PSK-3/5 8PSK-2/3 8PSK-3/4	8PSK-5/6 8PSK-8/9 8PSK-9/10 8PSK_AUTO* 16QAM-3/4 16QAM-7/8 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10
Symbol Rate	The number of symbols transmitted per second. The amount of data per symbol is dependant upon the modulation type, e.g. QPSK, 8PSK, etc.	Range can be determined by feature key.	
Acquisition Range	Acquisition Range is defined as the range of frequencies that the tuner will scan in order to achieve carrier synchronization. Allows the operator to select the range of frequencies that the RF tuner will sweep through to acquire the carrier. e.g. If the desired carrier is at 1.080GHz and the Acquisition Range is set to 5MHz, the RF tuner will sweep through 1.080GHz ± 2.5MHz to acquire the carrier. Units are in MHz. note: Actual acquisition range available is symbol rate dependent for advanced and premium demods. If symbol rate < 5MBaud, maximum range is 1.5 * symbol rate. If symbol rate > 5Mbaud, maximum range is 7.5MHz.	0 - 7.5MHz	
Rolloff	The rolloff selection will determine the shape of the input filter. The occupied bandwidth of the modulated signal is the symbol rate multiplied by $(1+\alpha)$ where alpha (α) is the rolloff factor (%). By using a lower alpha, carriers can be spaced closer together on a given transponder or an increased symbol rate can be realized for a given bandwidth. note: 5%, 10%, and 15% rolloff is only applicable in DVB-S2 with premium	5% 10% 15% 20% 25% 35% AUTO*	

	demodulators. AUTO is only available in DVB-S.	
Pilot	DVB-S2 allows the option of inserting bursts of pilot tones that are very robust and prevents the carrier recovery system from failing prematurely. However, when pilots are enabled, the total data rate throughput is reduced by approximately 3.0%. note: Pilot is not applicable in DVB-S or AUTO-CCM modes.	On Off N/A
FEC Frame Type*	When operating in DVB-S2, the Frame Type options are either Normal or Short. The Normal 64,800-bit FEC frame provides better protection but introduces more latency compared to the Short 16,200-bit FEC frame. Therefore, the Short FEC frame type should be selected in applications where latency is critical and the longer frame type should be used to optimize protection. note: FEC Frame type is not applicable in DVB-S or AUTO-CCM modes.	Short Normal N/A
LNB Menu		
LNB State	This configuration will enable or disable power on the input connector to power the LNB. If on, the user selected voltage and tone will be placed on the connector via the Polarity and Tone configurations.	ON OFF
LNB Polarity	This control is primarily used in "Universal" LNB applications. The LNB Polarity control allows for LNB polarization selection; the 13VDC source will select the Vertical polarity and the 18VDC source will select the horizontal polarity. For typical "C" and "Ku" band applications, the 18 VDC option is recommended.	H(18V) V(13V)
LNB Tone	This control is used only for Universal LNB applications. A universal LNB can route the high or low band from either polarity to the IRD. The high band is selected by enabling the 22 kHz tone and the low band is selected when the 0 Hz tone is enabled.	0KHz 22KHz
Profile Menu		
Save	Allows user to save currently running RF configuration to a profile. Press <select> then use keypad for custom name entry. Press <enter> to confirm name and save profile.	

Select	Allows user to load profile from list. Press <select> then <up> and <down> arrows to list profiles. press <enter> to load selected profile.	
Delete	Allows user to delete profile from list. Press <select> then <up> and <down> arrows to list profiles. press <enter> to delete selected profile.	

RF Rx Menu (LB L-Band)

Item	Function	Options
Tuner State	Enables or Disables RF input. note: When RF1 and RF2 are both enabled, maximum tuner performance is affected. Please view table in Appendix A for symbol rate and modcod resource limitations.	DISABLED ENABLED
Downlink	Allows the operator to enter the satellite downlink frequency. The value for the Downlink frequency is used with the Local Oscillator frequency to calculate the L-Band frequency. The Downlink and Local Oscillator frequencies can be used to determine if spectrum inversion occurs using the following rules. If the Downlink frequency is less than the Local Oscillator frequency, then spectrum inversion does occur. If the Downlink frequency is greater than the Local Oscillator frequency, then spectrum inversion does not occur.	Range dependent upon LO configuration
Local Oscillator	The Local Oscillator (L.O.) control specifies the frequency of the LNB local oscillator. The standard L.O. frequencies for "C" and "Ku" bands are 5150MHz and 10750MHz respectfully although, some other variants are included. If the desired L.O. frequency is not listed, select either C: Manual or Ku: Manual and enter the L.O. frequency in the Manual L.O. field.	C: 5150 KU: 11300 KU: 10750 KU: 10600 KU: 10000 KU: 9750 KU: 9600 C: MANUAL KU: MANUAL
Manual LO	Allows manual entry of the LNB Local Oscillator frequency provided that either C: Manual or Ku: Manual is selected from the Local Oscillator pulldown menu.	
L-Band	Allows the operator to enter the L-Band frequency within the range from 950MHz to 2.15GHz. The value entered in this field is used with the Local Oscillator frequency to calculate the Downlink frequency using the following rules. If Downlink < Local Oscillator, then Downlink -	950MHz - 2150MHz

	Local Oscillator = L-Band . If Downlink > Local Oscillator, then Downlink - Local Oscillator = L-Band	
Acquisition Range	Acquisition Range is defined as the range of frequencies that the tuner will scan in order to achieve carrier synchronization. Allows the operator to select the range of frequencies that the RF tuner will sweep through to acquire the carrier. e.g. If the desired carrier is at 1.080GHz and the Acquisition Range is set to 5MHz, the RF tuner will sweep through 1.080GHz ± 2.5MHz to acquire the carrier.	0 - 5MHz
S2X Rolloff	S2X Rolloff will allow the tuner to operate in an optimized mode for roll-offs of 15% or less. When disabled, it will operate in standard 20% - 35% as defined by the incoming S2 BBHeader. Due to modulation manufacturers providing backwards compatibility during S2 to S2X migration, this must be manually configured for the best 5%, 10% and 15% roll-off performance.	DISABLED ENABLED
LNB Polarity	This control is primarily used in "Universal" LNB applications. The LNB Polarity control allows for LNB polarization selection; the 13VDC source will select the Vertical polarity and the 18VDC source will select the horizontal polarity. For typical "C" and "Ku" band applications, the 18 VDC option is recommended.	OFF H(18V) V(13V)
LNB Tone	This control is used only for Universal LNB applications. A universal LNB can route the high or low band from either polarity to the IRD. The high band is selected by enabling the 22 kHz tone and the low band is selected when the 0 Hz tone is enabled.	0KHz 22KHz
Modulation Type	Allows the selection of the mod type.	AUTO DVBS DVBS-2
Symbol Rate	The number of symbols transmitted per second. The amount of data per symbol is dependant upon the modulation type, e.g. QPSK, 8PSK, etc. Set this field to 0 for automatic Symbol Rate.	0 = AUTO Range can be determined by feature key.
ISI	ISI (input stream identifier) is required for multistream applications. If a multistream RF source is detected, BBHeaders containing this value will be demodulated and output to the receiver. This value has no effect during single stream applications.	0 - 255
RF Stats Menu		
RF Stats	General RF Lock Status is provided via the RF	

	quickview menu, but a detailed list of further information can be found in this menu.	
--	---	--

IP Rx Menu

Item	Function	Options
Multicast RX IP	Multicast IPA sets the multicast receive Group IP address. IP Multicast receiving is supported from compatible streamers. The range of the multicast group IP is 224.XXX.XXX.XXX to 239.XXX.XXX.XXX - XXX represents any number 0 through 255. This can be either regular class A, B, C IP address or a multicast IP address.	0.0.0.0 - 255.255.255.255
Multicast RX Port	Port number are used for receiving UDP/RTP transfers in conjunction with Multicast IPA. The valid range is 0-65535. If the port number is set to 0, then no UDP transfers will take place. 2000 is default.	0 - 65535
Source Specific Multicast Address	Configures the multicast receive Source Specific IP Address. This configuration should be configured to 0.0.0.0 (any source multicast) in most IGMPv2 multicast applications. This configuration is an advanced configuration used for redundancy, security, or IGMPv3 multicast applications. It does not function for unicast reception.	0.0.0.0 - 255.255.255.255
Multicast Connector	The multicast connector configuration determines the physical port of where the IP stream will be received, the ethernet (10/100) or gigabit (10/100/1000) ethernet port.	ETHERNET GIGE
Latency	Multicast Latency sets the latency delay before the decoder begins playback from the multicast source and should be argued as a millisecond value. If the MULTICASTLATENCY delay time is too large, and the internal delay buffer is about to overflow, the system will start the multicast playback early to prevent the overflow. A log message is generated when this condition occurs.	4ms min. - max (rate dependent) 500ms (default)
Multicast Timeout	Sets the timeout value for return to normal video playback after video multicast packets are no longer detected. The default timeout value is 300 milliseconds. If the timeout	33 - 30000ms 300ms (default)

	value is set too low, the multicast receive may timeout during normal reception if the packet transmission is bursty.	
Multicast Error Recovery	Multicast Error Recovery sets the timeout value for recovery of multicast receive after decoder error condition is detected. The default error recovery timeout is configuration value is 10000 milliseconds.	33 - 600000ms 10000ms (default)

Video Menu

Item	Function	Options
Output Menu		
Fault Mode	Display or Modify the current SDI video fault setting. This setting sets the video resolution when in video fault. This setting will be applied on startup when no video is present. If video becomes present, the setting will be overridden by the current video setting.	480i59.94 576i50 720p59.94 720p50 1080i59.94 1080i50 1080p59.94 1080p50 1080p29.97 1080p25
Video Loss	When video is not detected on the configured input, this setting will define the output.	OFF:No video output on fault BLANK:Only blanking on fault BLANKTONES: Blanking and tones on fault BLANKOVERLAY: Blanking and overlay on fault BLANKTONESOVERLAY Blanking, tones and overlay on fault When a type with BLANK is selected, the current bars/matte setting will be applied. When a type with TONES is selected, the current tones setting will be applied. When a type with OVERLAY is selected, the current device name will be used.

3G Mapping Level SDI	SDI 3G Level controls the mapping of the 3G-SDI signal when decoding 1080P50, 1080P59.94 and 1080P60 streams. The 3G-SDI signal can be mapped to Level A or Level B Dual Link. The mapping is individually configurable for each set of outputs (SDI and SDIALT). If 3G-SDI output does not appear on the downstream device, the device may not support the currently configured mapping mode. Use SDI3GLEVEL to change the mapping mode.	A B
3G Mapping Level SDIALT	SDI 3G Level controls the mapping of the 3G-SDI signal when decoding 1080P50, 1080P59.94 and 1080P60 streams. The 3G-SDI signal can be mapped to Level A or Level B Dual Link. The mapping is individually configurable for each set of outputs (SDI and SDIALT). If 3G-SDI output does not appear on the downstream device, the device may not support the currently configured mapping mode. Use SDI3GLEVEL to change the mapping mode.	A B
Downscaling SDI	The Downscaling SDI setting determines whether the SDI bank (SDI Output 1 and 2) will be output natively or downscaled to SD.	OFF SD
Downscaling SDIALT	The Downscaling SDI setting determines whether the SDI bank (SDI Output 3 and 4) will be output natively or downscaled to SD.	OFF SD
Genlock Menu		
Genlock Mode	Configures the genlock operation of the decoder. SLAVE is primarily used for 3D applications and REMOTE is used in standard genlock operation.	OFF - Disables genlock SLAVE - Enable Genlock, Decode source is synchronous to SYNC IN signal REMOTE - Enable genlock, Decode source is NOT synchronous to SYNC

		IN signal
Horizontal Adjust	Horizontal adjustment defines the difference in the SYNC IN HSYNC and output HSYNC. Typically, this should be in the range of 0 to +1 line in clocks. For example, a 1080I output could be adjusted from 0 to 2200.	0 - 2200
Vertical Adjust	Vertical adjustment defines the difference in the SYNC IN VSYNC and output VSYNC. Typically, this should be in the range of 0 to +1 frame in lines. For example, a 1080I output could be adjusted from 0 to 1125.	0 - 1125
Pixel Phase	Pixel Phase adjustment is a very fine grain adjustment that can adjust within a single clock. The increments are 1/64th of a clock. The valid range is 0 to 63.	0 - 63
Genlock Status	Shows if GENLOCK input is currently being used for the decoder or in FREE RUN mode	
Genlock CVBS Out	This configuration is used generally with 3D applications. The 'MASTER' unit CVBS configuration must be configured as 'SYNC'.	VIDEO - CVBS output is video SYNC - CVBS output is black burst sync signal
Genlock Reset	Reinitializes the Genlock System.	

Audio Menu

Item	Function	Options
Audio Assign Order	The RD automatically assigns audio PID's to audio engines upon stream acquisition. This setting determines if the audio assignment should be done in PID Ascending order, the Adtec default, or PMT order. Some legacy IRD's use PMT order.	PID ORDER (default) PMT ORDER
Audio Sync Mode	Audio Sync Mode determines how the audio sub-system should behave with incoming transport streams. When it is desired for the audio subsystem to retain tight lipsync and adjust on upstream lip sync changes, this should be configured for Professional, the default setting. In rare cases, third party encoders or multiplexers may have unstable PCR/PTS timing. In these cases professional may cause intermittent drop outs as the audio sub-system attempts to retain tight lip sync. If this occurs, please change lipsync setting to Relaxed.	PROFESSIONAL (default) RELAXED_20_MS RELAXED_80_MS RELAXED_1_S
Audio 1-8		
Audio PID	Allows selection of available audio PID associated with program. note: Selection list only shows PIDs listed in PMT. Manual PID entry (such as IFB applications) is only available via the UI and SNMP at this time.	DISABLED AUTO (default) * shows PID list from actively decoding program
Offset Pair	Adjusts each individual pairs of audio sync.	-50 - 800ms

DolbyD Mode	<p>Configures the audio engine to Pass-through (COMPRESSED) or decode (2/0 STEREO) if a Dolby Digital AC3 PID is detected for the selected Audio input. Mpeg1Layer2 always decodes, and LPCM / Dolby E always Pass-through, regardless of this setting.</p> <p>Dolby Decode requires feature key capability.</p>	PASSTHRU (default) DECODE - STEREO*
DolbyE Line	<p>This is used to configure Dolby E placement in the SDI output and is configurable per audio engine. When set to AUTO (-1), the default configuration, the Dolby E line is placed within the valid line number range for the video resolution. The Dolby E line may be manually configured to a value within range. Valid ranges for Dolby E line placement are resolution and frame rate dependent. If the configured value is not valid, the system will use the valid line used by the 'AUTO' mode. The Dolby E line status information can be used to see the actual Dolby E line placement.</p> <p>View Dolby E line table for more information.</p>	-1 - 4096 -1 = AUTO
Analog Vol. Pair 1 & 2	Adjusts the analog volume of the first pair in dB increments	-49 - 18 dBu
SDI Audio Matrix 1-8		
SDI Audio Matrix	The SDI audio matrix allows the user to route, duplicate, or disable audio pairs within the SDI embedded output.	<p>DISABLE, Disable audio output on selected SDI pair</p> <p>AUTO, default, Invokes automatic SDI pair assignment. This is the default setting.</p> <p>AUDIO1, Route Audio 1 to the selected SDI pair</p> <p>AUDIO2, Route Audio 2 to the selected</p>

	<p>SDI pair</p> <p>AUDIO3, Route Audio 3 to the selected SDI pair</p> <p>AUDIO4, Route Audio 4 to the selected SDI pair</p> <p>AUDIO5, Route Audio 5 to the selected SDI pair</p> <p>AUDIO6, Route Audio 6 to the selected SDI pair</p> <p>AUDIO7, Route Audio 7 to the selected SDI pair</p> <p>AUDIO8, Route Audio 8 to the selected SDI pair</p>
--	---

VBI Menu

Item	Function	Options
SMPTE 2038 Pass-through	Configures the SDI ANC passthrough feature.	OFF ON
AFD		
SDI Line Number	Configures the SDI ANC line output of AFD (SDI Output Port 1 and 2)	0 - Disabled 7 - 22
SDI Alt. Line Number	Configures the SDI Alternate ANC line output of AFD (SDI Output Port 3 and 4)	0 - Disabled 7 - 22
Closed Captions		
CVBS Line Number	Enables/Disables the CVBS/SD-SDI port line number for waveform closed captions.	0 - Disabled 21 - Output captions if present
SDI Line Number	Configures the SDI ANC line output of EIA-608/708 Closed Captions (SDI Output Port 1 and 2)	0 - Disabled 7 - 22
SDI Alt. Line Number	Configures the SDI Alternate ANC line output of EIA-608/708 Closed Captions (SDI Output Port 3 and 4)	0 - Disabled 7 - 22
Teletext		
CVBS Line Number	Enables/Disables the CVBS/SD-SDI port line number for waveform Teletext.	0 - Disabled 22 - Output teletext if present
SDI Line Number	Configures the SDI ANC line output of OP47/Teletext (SDI Output Port 1 and 2)	0 - Disabled 7 - 22
SDI Alt. Line Number	Configures the SDI Alternate ANC line output of OP47/Teletext (SDI Output Port 1 and 2)	0 - Disabled 7 - 22

CAS Menu

Item	Function	Options
Mode	Configures the current decryption setting.	OFF BISS_1 BISS_E_USER_ID_ON E BISS_E_USER_ID_TW O
Clear Session Word	The session keys used for decryption. [MODE BISS_1] uses a 12-digit hexadecimal Clear Session Word.	user-defined using the numeric keypad
Encrypted Session Word	The 16-digit hexadecimal Encrypted Session Word for use with BISS_E modes.	user-defined using the numeric keypad
User ID One	Valid in Mode BISS_E_USER_ID_ONE ONLY. The 14-digit hexadecimal User ID (injected ID) used for decryption.	user-defined using the numeric keypad
User ID Two	Valid in Mode BISS_E_USER_ID_ONE ONLY. The 14-digit hexadecimal User ID (injected ID) used for decryption.	user-defined using the numeric keypad
TS Out Decrypt	<p>The TS Out Decrypt configuration determines if the ASI output should mirror the selected input (OFF), thus preserving any encrypted streams or if it should be decrypted / free to air (ON).</p> <p>OFF, the default configuration, is recommended for users needing to redistribute transport streams in their original form. The decoder will decrypt / decode the selected program with the entered BISS key, but the ASI output will remain unaltered.</p> <p>ON is recommended for users needing to redistribute the ASI output as a free to air SPTS/MPTS. All programs will be decrypted with the user entered BISS key.</p>	OFF ON

IP Tx Menu

Note: this is a parallel menu. It has four indices. Use the left or right arrows to navigate to desired index.

Item	Function	Options
IP Tx 1 - 4		
Mode	Enables IP Egress.	OFF SEND
Tx IP Address	The IP Address of which the Multicast or Unicast is broadcast. Multicast addressing supports the transmission of a single IP datagram to multiple receivers. Valid Multicast addressing range is 224.10.XXX.XXX to 239.XXX.XXX.XXX. Unicast addressing sends a single IP datagram to only one receiver. The Unicast address will be the unique IP of the receiving device.	user-defined; numeric field in format xxx.xxx.xxx.xxx
Tx Port	port assignment used for transmitting a multicast	user-defined using the numeric keypad
Tx GW Address	The Unicast Gateway automatically handles IP routing for unicast transmissions. This must be configured if the outgoing unicast requires a different gateway from the configured system default gateway. A route is automatically added when the unit is configured for transmit and a Unicast Gateway exists. The route is deleted if set to 0.0.0.0 or Multicast Mode set to OFF.	user-defined; numeric field in format xxx.xxx.xxx.xxx
DVB per IP	Configures the amount of DVB transport stream packets (188 bytes per DVB packet) per IP packet payload	1 4 7
RTP	allows for sequence numbering and timing	OFF (UDP) ON (RTP)
FEC Mode	Forward Edge Correction; selects on/off. When selected, sends two FEC RTP streams in addition to a source RTP stream enabling a receiver to reconstruct missing packets in the source stream.	OFF ON MAXBURST BURST LOWLATENCY
FEC L	affects the maximum burst packet loss	4-20

	that can be recovered Note: The product of FEC L and FEC D cannot exceed a value of 100	
FEC D	defines latency involved in burst recovery	4-20
TOS	Allows the operator to sets the TOS bits in the IPv4 header of the TSoIP payload	0 = Normal service 2 = Minimize monetary cost 4 = Maximum reliability 8 = Maximize throughput 16 = Minimize delay
TTL	Time-to-Live; specifies the number of iterations or transmissions the packet can undergo before it is discarded	user-defined using the numeric keypad
Tx Connector	sets the physical connector (on the rear of the unit) to use for multicast transmit purposes on the indicated encode channel.	IP 1 IP 2

System Menu

Login

Units ship with the front panel logged in by default. If you become logged out and are prompted for a password, use the following key sequence for access.

note: The key sequence can be remembered by using the word 'USER' for '**Up**, **Select**, **Enter**, **Right**'.

Action
Press <Select>
Press <Up> arrow
Press <Select>
Press <Enter>
Press <Right> arrow
Press <Enter>

Duration

The front panel also has a login duration feature. This setting allows the user to specify a time frame (in minutes) until the unit will automatically log itself out.

Action
Press mode until you see the System Menu.
Press <Select>
Press the <Down> arrow
Press <Select>
Using the <Up> and <Down> arrows, select the value you wish.
Press <Enter> to save your selection

Possible Configurations:

0 (Zero): The unit will not automatically log out.

1-9: The duration of time, in minutes, before the unit logs out, if no input is received.

Item	Function	Options
Network Menu		
Ethernet IP Address	This is the address of your device on your network specific to the Ethernet Port.	user-defined using the numeric keypad Default is 192.168.10.48
Ethernet Mask	Defines the unit relative to the rest of your network.	user-defined using the numeric keypad Default is 255.255.255.0
Ethernet DHCP	The Dynamic Host Configuration Protocol allows your device to self-locate network Ethernet parameters.	On (finds own DHCP Address) Off (defaults to last entered IP Address) Default is OFF
GigE IP Address	This is the address of your device on your network specific to the GigE Port.	user-defined using the numeric keypad Default is 192.168.20.48
GigE Mask	Defines the unit relative to the rest of your network.	user-defined using the numeric keypad Default is 255.255.255.0
GigE DHCP	The Dynamic Host Configuration Protocol allows your device to self-locate network GigE parameters.	On (finds own DHCP Address) Off (defaults to last entered IP Address) Default is OFF
Gateway IP Address	The gateway is a routing mechanism that passes traffic between different subnets and networks.	user-defined using the numeric keypad Default is 192.168.10.1
Stealth IP Address	This is a security feature that allows only the designated Stealth IP Address to communicate with the unit for FTP and other services. This control allows one-point override	user-defined using the numeric keypad Default is 0.0.0.0. Using all 0s effectively turns this function off.

	access to the Stealth IP Address.	
Time Menu		
Time	Defines system time	user-defined using the numeric keypad
Timezone	Defines the time zone the unit operates in	
NTP Menu		
NTP Status	Network Time Protocol SYNC status	Read-only
NTP IP Address	IP address designated for Network Time Protocol	<p>user-defined using the numeric keypad</p> <p>Default is 0.0.0.0. Using all 0's effectively turns this function off.</p>
Alarm Menu		
Event Record	Log of events outside of regular operating parameters	scroll up and down to view log items
SNMP Menu		
SNMP	Controls the status (ON/OFF) of the Simple Network Management Protocol (SNMP) feature. We support SNMPv2c.	OFF ON
Read-only community	The Simple Network Management Protocol (SNMP) Read-Only Password. Default Value: "adtec"	user-defined using the numeric keypad default: adtec
Read-write community	The Simple Network Management Protocol (SNMP) Read-Write Password. Default Value: "none"	user-defined using the numeric keypad default: none
Trap Community	The Simple Network Management Protocol (SNMP) trap community. Default Value: "public"	user-defined using the numeric keypad
Trap Sink	The Simple Network Management Protocol (SNMP) trap sink, destination for sending SNMP traps. Default Value: "127.0.0.1" / localhost.	user-defined using the numeric keypad

Com2

Item	Function	Options
Com2 Settings	RS-232 terminal monitor for communicating with the internal host motherboard for diagnostics.	115200 8 1 NONE 57600 8 1 NONE 38400 8 1 NONE 19200 8 1 NONE 9600 8 1 NONE Default is 38400 8 1 None

Host Name

Item	Function	Options
Host Name	The hostname of the unit. This name is be used by unit to broadcast zero-conf name and is viewable in web-browser title bar	Read-Only

Firmware

Item	Function	Options
Firmware Version	Reports the currently running firmware version of your device.	Read-Only

Feature Menu


Item	Function	Options
Permanent ID	Shows the units unique permanent identifier. This ID is required by support when purchasing unit capability keys.	Read-Only
Temporary ID	Shows the units unique temporary identifier. This ID is required by support to provide temporary unit capability keys. If all 0's, your unit is not	Read-Only

	temporary key capable.	
--	------------------------	--

Profile Menu

Item	Function	Options
Last Loaded Profile	Displays the last profile loaded	**
Select	The select submenu lists all stored profiles and allows loading	**
Save	The save submenu saves a profile with a user designated name	**
Delete	The delete submenu deletes a profile from the available list	**

Back Panel



Connector	Description
Processor	
Power 1 & 2	Redundant AC Power, Standard 3 pin computer power plug (Auto range 70-240 VAC Input)
GigE	UDP or RTP multicast transport ingress port (SMPTE 2022)
COM2	API Serial Communication Interface **
COM1	Serial Port Used for Troubleshooting (Terminal)
Ethernet	10/100 base T ethernet interface (Monitoring/Management)
DVC Parport	9-pin parallel I/O interface for control systems **
RS422	Not Currently Supported **
GPIO	Tally and Control Port
Decoder	
Analog Audio Out	Balanced analog audio out. Stereo pairs 1 & 2 (600 Ohm Balanced)
AES Audio Out 1-8	x8 75 Ohm AES-3 BNC

ASI/SDI In	75 Ohm terminated BNC input. SDI input features are not active at this time.
x3 ASI OUT	x3 75 Ohm BNC ASI output per EN5000839
Sync In	Standard analog video sync separation for NTSC, PAL, 480I/P, 576I/P, 720P, and 1080I/P/PsF from Composite Video (CVBS). Bi-level & tri-level sync compatible. BNC
CVBS Out	75 Ohm BNC Standard Definition Composite Video Output
HDMI Out	HDMI 1.3 Compliant Output.
SDI Out Banks	<p>x4 Outputs from decoder: Video/Audio/VBI (SMPTE 259M-C - SD, SMPTE 292M - HD, SMPTE 424M - 3G).</p> <p>SDI Bank A = x2 SD/HD/3G-SDI BNC Outputs SDIALT Bank B = x1 SFP(for Optical SFP connector) SD/HD/3G-SDI Output and x1 SD/HD/3G-SDI BNC.</p> <p>note*: 3G-SDI Outputs have selectable Level A and Level B Dual Link output control to retain interoperability with other third party 3G devices. The default mapping level is Level A.</p>
Demodulator (Optional)	
RF 1 & 2	x2 RF Input, 75 Ohm F-Connector


DB9-M Analog audio output pinout

PIN	Designation	Function
1	NC	No Connect
2	GND	Ground
3	L+	Left +
4	R+	Right +
5	GND	Ground
6	NC	No Connect
7	GND	Ground
8	L-	Left -
9	R-	Right -

COM1/COM2 to DB9 Serial Adapter

The COM1 and COM2 port is an industry standard RS-232 DTE device on RJ45/RJ48. Units ship with RJ45 to DB9 adapters that are pinned per the following.

DB9 Pin	DB9 Function	RJ45 Pin	RJ45 Function
1	Carrier Detect (CD)	2	No Connect / Carrier Detect (DCD)
2	Receive Data (RXD)	6	Transmit Data (TXD)
3	Transmit Data (TXD)	5	Receive Data (RXD)
4	Data Terminal Ready (DTR)	1	Data Set Ready (DSR)
5	Ground (GND)	4	Ground (GND)
6	Data Set Ready (DSR)	3	Data Terminal Ready (DTR)
7	Request to Send (RTS)	7	Clear to Send (CTS)
8	Clear to Send (CTS)	8	Request to Send (RTS)
9	Ring Indicator (RI)	NC / NA	No Connect / Not available on RJ45



GPIO and Parport information

The GPIO port allows decoder control and TTL voltage output for monitoring systems. The GPIO feature is not enabled at this time.

The DVC Parport allows custom events to be programmed upon input pin voltage change. It contains 4 available inputs for custom commands. Please contact technical support for advanced usage in programming the parallel port.

GPIO Pinout

PIN	Designation	Function
1	NC	No Connect
2	D3	reserved for future functionality

3	D2	reserved for future functionality
4	D1	reserved for future functionality
5	D0	reserved for future functionality
6	NC	No Connect
7	5VDC	+5V DC
8	GND	ground
9	TTL Tally	reserved for future functionality

Parport Pinout

PIN	Designation	Function
1	NC	No Connect
2	D3	Data bit 3 (input)
3	D2	Data bit 2 (input)
4	D1	Data bit 1 (input)
5	D0	Data bit 0 (input)
6	NC	No Connect
7	5VDC	+5V DC
8	GND	ground
9	NC	No Connect

Chapter 2 - Getting Connected

Introduction to the Control Application

A web-based control software application comes pre-installed on the RD-70.

Compatible browsers

Firefox (recommended)

MS Internet Explorer

Safari

Chrome

Ethernet Access

To begin, you will need to connect to your RD-70 via Ethernet directly, or by adding the RD-70 to your local area network. The default address for all Adtec devices is 192.168.10.48.

To connect directly to the device, make sure that your computer and the device have IP addresses within the same IP class range.
(ex. 192.168.10.48 for the device and 192.168.10.49 for your computer).

If you need to change the IP address of the device, this can be done via the front panel, System > Network menu. Using a CAT 5 crossover cable, connect one end to your computer and the other to the Ethernet port found on the processor section of the back panel. (Some computers can auto negotiate the connection and a crossover may not be necessary.)

To add the device to a LAN, connect a standard CAT 5 Ethernet cable to your network router and then to the Ethernet port on the back of the device. If your network is DHCP enabled and you prefer that over a static IP, you can turn on DHCP for the device via the front panel, System > Network menu.

Zero Configuration Access

Adtec Digital has adopted zero-configuration networking technology, streamlining the setup and configuration processes for our products. The use of this technology enables automatic discovery of Adtec devices and services on an IP network. Used in tandem with the web-based control and configuration applications we can now provide 1-click access to any device.

By using the built-in Bonjour locator in Apple's Safari browser or the plug-ins readily available for IE or Firefox browsers, users can locate all of the Adtec devices on a network by referencing the serial number on the back of the device. Clicking on the unit in the Bonjour list will re-route you to a login page. If you do not wish to use Bonjour, you can reach the device's web application by pointing your browser to the IP Address of the device. Ex.<http://192.168.10.48/>.

Login

Once you reach the default login page for the web-based application, you will need to login by pressing the login button. You will be prompted for a username and password. The default username is 'adtec'. The default password is 'none'.

The left-hand panel of the application will report current status in real-time while the right panel tabs will allow you to configure your device. As you navigate through the web application look for the ? icons associated with each parameter. By clicking on these question marks, you can view additional information about how the parameter is used.

Chapter 3 - Operational Information

DVB-S / DVB-S2 AUTO Modes (ADV and PRM option)

The RD-70 Advanced and Premium demodulators support automatic modulation and coding mode detection. When the unit is configured for DVB-S or DVB-S2, the minimum configuration required is L-Band frequency and symbol rate. In DVB-S mode, selecting QPSK_AUTO or 8PSK_AUTO from modulation mode will automatically detect the coding scheme for DVB-S modulated carriers. For DVB-S2 modes, selecting AUTO-CCM from the CCM configuration will automatically detect the modulation and coding scheme for DVB-S2 modulated carriers.

DVB-S / DVB-S2 AUTO Modes (LB option)

The RD-70 with L-Band demodulator (LB) option supports automatic detection of modulation type and symbol rate on two RF inputs. In fully automatic mode, the minimum configuration requirement is L-Band frequency. The demodulator is running in fully automatic mode when the type is set to 'AUTO' and the symbol rate is set to '0' or 'AUTO'.

Notes about demodulator:

- Please note that some carriers may not fully acquire if they fall outside of the allocated resources available by the hardware. Please reference the demodulation resource [table](#) located in the appendix for supported modes.

DVB-S2 - Recommended use of Pilots

The use of DVB-S2 pilots within the modulated carrier are recommended under certain conditions. With the following configurations, Pilots are recommended:

- High order modulation schemes: 16APSK and 32APSK
- Low code rates QPSK: 1/4, 1/3, 2/5, 1/2, and 3/5
- Low code rates 8PSK: 3/5, 2/3, 3/4, and 5/6
- Low symbol rates: <5 Mbaud for free running DRO LNB
- Low symbol rates: <3 Mbaud for Phase Locked DRO LNB


How to use RF Profiles (LB option)

The RD has capability to create profiles from the current running RF configuration and load it at a later time.

To create a profile:

- Enter the desired RF parameters required for the profile

- Click the Apply button to save information to the currently running configuration
- Click the 'Create RF Profile' button next to the respective tuner that is desired to be stored.
- Name the RF Profile and click OK. Please note that only Alphanumeric and underscores are allowed in the profile name. If Spaces " ", Dashes "-", or other special characters are entered, an error window will pop up.
- All drop downs will populate with the created RF profile name



To load a profile:

- Select an RF profile from the 'Select Profile' list above the desired tuner.
- After selection, the profile will be "previewed" and all configuration fields will display the contents of the profile.
- If the profile is desired to be loaded into the respective tuner, click the Apply button. If the profile is not desired, the Cancel button may be clicked or the double dash profile "--" may be selected to exit from preview mode. Exiting preview mode will return to display the current running configuration.

Profile Management:

- The Manage RF Profiles box gives users the ability to Delete (Red X button) or Download (Downward Yellow button) RF Profiles from the IRD.
- Select a Profile and click the Delete button to have the profile removed from the device and all drop down boxes.
- Select a Profile and click the Download button to have the profile downloaded to your PC.
- The standard Upload button next to the Logs and Thumbnail button may be used to Upload a profile to other devices.



UDP / RTP / FEC / TCP IP Rx

The RD-70 supports a number of IP based protocols for the reception of transport streams via private and public networks. The RD-70 will automatically determine if an IP stream is UDP, RTP, or a SMPTE-2022 FEC stream. TCP reception is a less common implementation for transmission of broadcast transport streams, but has recently been added to the RD-70.

UDP (User Datagram Protocol) multicast/unicast streams are commonly used for broadcast transport streams in local or private networks that contain little to no packet loss. UDP offers no protection against dropped packets or packets received out of order (usually due to packets taking a different amount of time to traverse network devices). Due to the low reliability of UDP, it is NOT recommended to be used over the public internet or in environments where the potential of packet loss, increased jitter, or out of order packets is high. If packets are lost or received out of order, service anomalies will occur. The RD-70 supports up to 100Mb/s when a 7 DVB Packet payload exists for each UDP packet.


RTP (Real-time Transport Protocol) is another type of multicast/unicast stream that is better to use than UDP in some environments. RTP is built upon the building blocks of UDP, but adds packet sequence identification. Packet sequencing gives a receiver the information needed to detect and correct packets that were received 'out of order'. RTP is highly recommended when timely delivery of each consecutive packet may not be guaranteed. The RD-70 supports up to 100Mb/s when a 7 DVB Packet payload exists for each RTP packet.

RTP + FEC or SMPTE-2022 is an additional method used in dealing with lost packets, where RTP alone can only tolerate packets received out of order. FEC (Forward Error Correction) streams add overhead to the overall data rate, but add protection in case of a lost packet. FEC (detection and correction of lost packets) adds latency and data overhead as opposed to UDP where no protection mechanisms exist. The amount of packet redundancy and overhead can be configured at the RTP/FEC transmitter. Each multicast/unicast FEC stream is transmitted on base port N and two FEC streams are sent on N+2 and N+4 respectively. When receiving FEC streams behind firewalls, please bear in mind that two additional ports (N+2 and N+4) must be allowed through for proper error recovery to occur. The RD-70

supports up to 45Mb/s SMPTE-2022 when a 7 DVB Packet payload exists for each RTP packet.

TCP (Transmission Control Protocol) support, a connection based protocol, has recently been added at an attempt to overcome some of the fundamental limitations of UDP and RTP. UDP and RTP are 'one way street' types of protocols where the transmitter sends data and never knows if the data makes it to the destination. TCP streams generally have higher latency (takes longer to transmit data and verify data has been transmitted), but are more reliable because each packet is accounted for by the receiver. If a packet is lost, the transmitter will be informed to re-transmit the packet. The transmitter and receiver continue to communicate about the quality of the reception and attempt to adjust packet delivery accordingly. The TCP mechanism when combined with large IP receive buffers can be more forgiving with packet loss, jitter, and out of order packets. The RD-70 supports up to 15 Mb/s when a 7 DVB Packet payload exists for each TCP packet. Multicast is *not* supported with TCP streams.

The RD-70 supports both unicast (point to point) and multicast (broadcast) streams. The RD-70 operates in UDP/RTP mode by default. To setup an IP Rx session, first configure the IP Rx operation mode. A unit reboot is required (WebUI asks for confirmation when changing) when changing between UDP/RTP Rx and TCP Rx modes.



Multicast Reception - Address

To receive a multicast (UDP/RTP/SMPTE2022) stream, place the multicast address wished to view in the 'Address' field. This address must match the same address used on the multicast transmitter. Multicast IP address ranges are 224.xxx.xxx.xxx to 239.xxx.xxx.xxx, where 0 <= xxx <= 255. If you are new to multicast and attempting a first time connection, 226.0.1.1 is a common address to start with. Please verify transmitter address configuration.

Optionally, the source specific multicast address (The actual IP address of the sending device) may be entered for IGMPv3 applications. Configuring the Source Address will allow multicasts to be received from the entered address and entered address only. This configuration is non-functional for Unicasts. For IGMPv2 applications, the source address recommendation is 0.0.0.0.

Unicast Reception - Address

To receive a unicast (TCP/UDP/RTP/SMPTE2022) stream, enter 0.0.0.0 in the 'Address' field. The unit will be 'listening' for any streams sent directly to it. Refer to your IP transmitter documentation for proper configuration of the transmitter.

Unicast/Multicast Reception

Enter the port number in the 'port' field. The port number must match the port number used on the transmitter where the range is 0 to 65535. When 0, multicast is disabled. If you are new to multicast and attempting a first time connection, 2000 is a common port to start with. Please verify transmitter port configuration.

Choose the IP Rx 'Connector' dependent upon your network setup. Adtec recommends using the GigE port for all IP receptions.

Once IP Rx is configured, click Apply.

Visit the Input -> Service tab and click the 'Select first found' radio button to enable IP reception. IP service names will populate in the service list.

RD-70

Version 0.02.00
Temperature: 34(C)

Decoder Status:

Status:	DECODING IP
Transmux Rate:	31000037 (b/s)
Service ID-Name:	1-EN-81 ...
Service Provider:	Adtec Digital
Bars/Tones/ID:	OFF/OFF/OFF
Decrypt Status:	Decrypting

RF Status:

Active Input:	RF 1
Status:	LOCKED
Receiver Level:	-54.49 dBm
Es/No(DVB-S2):	22.68 dB
Link Margin:	9.17 dB
Mode / FEC:	32APSK_3/4
Pilot:	ON
Interface Rate:	124.120864 (Mb/s)

IP Status:

Status:	PLAYING
IP Addr./Port:	226.0.55.92/2000
Average Bitrate:	31000037 (b/s)
Buffer %/Level:	18% / 506 (ms)
Protocol:	RTP
FEC Detected:	YES
FEC L/D:	20 / 4
DVB per IP:	7

Services

Select first found				
Select	Service ID	Service Name	Service Provider	Details
Select	1	EN-81	Adtec Digital	Details

Select first found				
Select	Service ID	Service Name	Service Provider	Details
Select	1	EN-81	Adtec Digital	Details
Select	2	EN-91	Adtec Digital	Details
Select	3	EN-81	Adtec Digital	Details
Select	4	EN-91	Adtec Digital	Details

Select first found				
Select	Service ID	Service Name	Service Provider	Details
-- No Services Found --				

Select first found				
Select	Service ID	Service Name	Service Provider	Details
Select	1	EN-81	Adtec Digital	Details

'Select first found' is also available via the Front Panel -> Services Menu -> Select First configuration. Use the left/right arrows to select [IP], press select, then press enter to start IP receiving.

Dolby E, Dolby D, LPCM, and Mpeg 1 Layer 2

As of 0.01.00 firmware, the RD-70 supports 16 channels of SDI embedded audio output with support of up to four audio pass-throughs, up to 8 pairs (sixteen channels) of aligned Mpeg 1 Layer 2 audio, and up to 8 pairs of Dolby Digital decoding. An audio pass-through consists of a Dolby E 20 Bit, Dolby E 16 Bit, Dolby Digital, or a Linear PCM stream that is preserved (not decoded) from the transport stream and embedded on the SDI output.

Mpeg 1 Layer 2 decode support includes 48kHz 32 - 384kbps. Interoperability support includes stream type 0x03 (sometimes called Mpeg 1 Layer 2), stream type 0x04 (sometimes called Mpeg 2 Layer 2), PES aligned/unaligned audio, Mono (with audio duplication feature), Dual Mono, and Stereo decoding.

Dolby Digital decode support includes a stereo output pair for each Dolby Digital Audio PID assignment (multi-channel Dolby Digital 5.1 for example is down-mixed to 2/0).

Note: Encoder must support alignment for aligned audio feature.

The RD-70 automatically configures the audio engines upon acquisition of a program when engines and sdi matrix are configured to 'AUTO'. The audio is automatically output based on ascending audio PID order from the selected program, not PMT order, to retain encoder compatibilities. The left hand status panel of the Web UI shows current active SDI audio output. Advanced configuration is available via the Audio tab for users that need to select custom PID's, disable audios, and duplicate audio pairs.

Dolby E line placement is handled automatically to meet Dolby Labs specification. Some users may need custom line placement. If the customer Dolby E line placement selection is out of specification, the RD will revert line placement to the automatic in range value. Please see [table](#) in notes for Dolby E line placement recommendations.

Notes:

- Encoder must support alignment for aligned audio feature.
- Pass-through audio bit-rates are now displayed on the left hand status panel. Please note that these are live calculated bit-rates and will not show a static number.

Dolby Labs - Dolby E recommended line position table

	625 25	1080i 50	1080 p 50	720p 50	525 29.97	1080i 59.94	1080p 59.94	720p 59.94
Earliest	8	13	26	17	12	18	35	23
Ideal -80us	11	19	37	25	13	21	42	28
Ideal +- 80us	12	21	42	28	14	24	47	32
Ideal +80us	13	23	103	31	16	26	52	35
Latest	30	53	105	70	26	48	95	63
Adtec Auto	19	30	42	35	19	30	47	40

AFD - Active Format Description

Active Format Description (AFD) contains aspect ratio and handling information utilized to aid in picture presentation of downstream devices. This is used most often by down-converters and set top boxes.

AFD carriage can be carried within a transport stream as a unique ANC PID (ancillary pid), within the video elementary stream as SEI data (H264), or user data (MPEG2). The RD-70 does not support AFD via an ANC PID at this time.

The RD-70 AFD implementation preserves the native AFD code from the video elementary stream and is inserted into the SDI ancillary data output on DID/SDID 0x4105. The SDI output is not modified in anyway based upon this data. SDI line number for AFD carriage is configurable via the VBI tab. The DID/SDID, AFD code, and aspect ratio flag can be seen in the VBI Output table via the VBI tab.

Genlock System

The RD-70 can synchronize its SDI and CVBS outputs to an external sync signal using the SYNC IN input and the Genlock control system. The SYNC IN input signal's frame synchronization is used to generate SDI and CVBS output pixel clocks, frame synchronization and audio clocks that are locked to the SYNC IN reference. The video decoder will automatically skip or repeat video frames as needed to adjust to differences between the SYNC IN clock and the decoder source clock (which is synchronized to the stream's PCR data). The audio system uses a sample rate converter to adjust to differences between the decoder source clock and the SYNC IN clock.

The Genlock system will automatically cross lock for all resolutions within the 59.94Hz standards or all resolutions within the 50 Hz standards. It does not cross lock between 50Hz and 59.94Hz standards at this time. This allows the SYNC IN signal to be valid for compatible decoded streams (EG: An NTSC black burst SYNC IN signal can be used to Genlock a 1080I59 feed).

The Genlock system can be configured in two modes. Genlock *SLAVE* mode is used when the SYNC IN signal is synchronous with the decoded stream (both signals are using the same 27MHz source clock). This mode allows two RD-70's to be used for receiving 3D/4K signals or when the decoded source is using the same clock base as the SYNC IN. This mode bypasses the need for the audio sample rate converters. Genlock *REMOTE* mode is used when the SYNC IN signal does not use the same 27MHz clock source as the decoded stream. This mode enables the audio sample rate converters for audio output.

The SYNC IN input will accept standard analog video sync for NTSC, PAL, 480I/P, 576I/P, 720P, and 1080I/P from Composite Video (CVBS). The input can accept Bi-level and Tri-level sync signals. The signal is processed to create synchronous audio and video clocks and to frame align the SDI and CVBS outputs with the input sync signal. Generally, the output will be automatically aligned within a few pixel clocks of the input.

If the Genlock system is locked, and the SYNC IN is removed, the system will attempt to maintain the clocks and frame reference with the last known locked frequency. There may be some clock drift over time. If the decoder is stopped and restarted in this mode, the Genlock system will use the decode source clock and operate in a 'free-run' mode until the reference is re-applied. The video and audio will be lost for a short time when the SYNC IN reference is restored.


When the Genlock mode is changed, the Genlock system will automatically be reset. This will cause a brief disturbance of the video and audio outputs.

TS Out Decrypt


TSO or Transport Stream Out Decrypt is a newer feature of the RD product line that determines how BISS encrypted transport streams are processed. This configuration provides end users flexibility in how the RD is used. The TS Out Decrypt configuration

determines if the ASI output should mirror the selected input (OFF), thus preserving any encrypted streams or if it should be decrypted / free to air (ON).

TS Out Decrypt should be set to OFF, the default configuration, if the IRD is to be used in a confidence decode / turn around application. A confidence decode / turn around application can involve the IRD being used a turn around device (IP to ASI or RF to ASI) where the user wants to preserve encryption on the ASI output, but also wants to decode one of the incoming programs. This configuration also allows the RD to ingest encrypted MPTS streams that may be over the TSO limit. A sample diagram of how the transport stream is passed to the ASI output through the system is shown below.



If the user wants to use the IRD as a decoder and decrypter, the TS Out Decrypt configuration should be set to ON. All programs will be decrypted with the user supplied BISS key and transported to the ASI output. This application is useful for users that want to redistribute the stream to other non-BISS devices, such as transport stream analyzers or third party decoders. Please note that when in this mode, total transport stream throughput must not exceed the rate stated in the Technical Specifications found in Appendix B.



Service Filtering

Terminology:

TS - Transport Stream - A stream of transport packets that contain audio, video and data belonging to one (SPTS, single program transport stream, also known as SCPC.) or several programs (MPTS, multiple program transport stream, also known as MCPC.).

PAT - Program Association Table. This MPEG-2 table lists all the programs contained in the transport stream and shows the PID value for the PMT associated with each program. The PAT is always found on PID 0x0000.


PMT - Program Map Table. This MPEG-2 table specifies PID values for components of programs.

PID - Packet Identifier. This unique integer value identifies elements in the transport stream such as tables, data, or the audio for a specific program.

Program / Service / Channel - A combination of one or more elements (video, audio or data) defined by a PMT.


Summary:

Service Filtering allows an MPTS from the input to be turned into an SPTS or program reduced MPTS on a given output. This is helpful in service turn around applications where all programs are not desired for re-transmission. An example of 5 MPTS to smaller MPTS outputs is shown below.



5 Service to 2 ASI Service Filtering, multi-service filter

The Adtec RD-70 also has the ability to route Inputs to Outputs, such as route ASI Input to IP Output and/or RF Input to ASI Output. The RD-70 does *not* support multiplexing of the inputs. Each IP destination also has unique filtering capabilities. A block diagram of the input routing and filtering is shown below.



The SVC-FILTR key must be enabled to configure Service Filtering. When filtering is enabled, a maximum of 5 programs are allowed on any given output. If filtering is disabled, all programs available on the input are available on the output, ie, unit is in service pass through mode.

Configure Service Filter on ASI

To configure service filtering on the ASI output, visit the TS Output -> ASI Tx tab. First choose your ASI Output Source. The ASI Output can be sourced from ASI IN, RF1 IN, RF2 IN or IP IN, depending on demodulator hardware options. Single tuner demodulators will have an RF option instead of RF1 and RF2.

Then, choose the ASI Output rate behavior or ASI Output TMR. ASI Output TMR determines the ASI egress rate. When set to AUTO, the default, the output rate will be the sum of all filter PIDs configured for the output + minimal NULL stuffing. When set to NATIVE, the output TMR is set to match the INPUT source TMR. MANUAL is a user defined rate.

Then, choose the service required to filter from the Available Service list. Clicking the right arrow will add the service to the Assigned Service list.

When the ASI Filter is set to ENABLED and Apply is clicked, you shall now see the selected service on the ASI Output.

Input Video Audio CAS VBI TS Output System Security Upgrade Help

ASI Tx IP Tx

Apply Cancel

ASI Service Filter ?

ASI Filter: ?	ENABLED	ASI Output Source: ?	ASI
ASI Output TMR: ?	NATIVE	Manual TMR (Mb/s):	AUTO
Available Services 4 - Adtec 2	AUTO NATIVE MANUAL	Assigned Services 3 - Adtec 1 Inactive Inactive Inactive Inactive	>> <<

Apply Cancel

Firmware Upgrade via Web User Interface

Periodically, we will provide firmware updates to our products via our website. (<http://www.adtecdigital.com>) To upgrade your device, download the firmware file from our website and store it locally. Login to the web-based application and navigate to the Upgrade > Firmware tab. Click on the upload button located at the top right of the application. Select the firmware file from your local machine and wait for it to upload. Once it has finished uploading, it will appear in the Available Versions list.

The screenshot shows the RD-70 web interface. On the left, there are several status tabs: Decoder Status, RF Status, IP Status, Video Status, and Audio Status. The Decoder Status tab shows DECODING ASI 100350272 (b/s). The RF Status tab displays Active Input RF 1, Status LOCKED, and Receiver Level -46.73 dBm. The Video Status tab lists Video Rate 24311820 (b/s), CODEC/Chroma H264 / 422, Bit Depth 10, Format 1920x1080 59.94p, SDIOUT Scale OFF, SDIALT Scale OFF, and Video / PCR PID 42 / 42. The Audio Status tab is partially visible. On the right, the Firmware tab is active, showing 'Installed Firmware Versions' and 'Available Firmware Versions'. The Installed Versions list contains 'Version 0.00.08' and 'Version 2013-06-11_19-27-36 (*** current selection ***)', with 'Select' and 'Delete' buttons. The Available Versions list contains 'Version 0.00.08' with 'Install' and 'Delete' buttons. Below these is the 'Adtec Digital Uploader' window, which shows a file named 'RD-70-v0.00.08.nfcms.tgz' is being uploaded, with a progress bar at 100% Complete.

Click on the Install button associated with the new file. Wait for it to completely extract and become available in the Installed Versions List. Once available there, simply click on the Select button associate with the new firmware and wait for your device to reboot.

Demodulator Firmware Upgrade via Web User Interface

In some cases, Adtec may provide a modulator or demodulator firmware upgrade. These are handled separately than standard product firmware upgrades because they can take longer than a product firmware update and should be planned during maintenance windows. Adtec currently has several demodulator versions that include ADV, LB and PRM models. Each demodulator hardware type has a unique demod firmware version and must be upgraded with a compatible version.

To upgrade, first determine the installed demodulator type and firmware version. Visit the Upgrade -> Features tab. The 'BOARDS INFO' table slot 99 will contain the installed demodulator version.

BOARDS INFO		
Slot ▾	ID	Name
2	BI20	PCA111 ver 2.0
99	7044AB	PRM ver 1.17

The above example shows a PRM demod running demod version 1.17. In this case, a 7044AB firmware file name is required to update this demodulator. If a demodulator firmware is provided for any reason, please make sure the firmware type provided matches the hardware type of the unit it is being installed on. The demod firmware may be upgraded similarly to a product firmware upgrade.

Click on the upload button located at the top right of the application. Select the firmware file from the local computer and wait for it to upload. Once it has finished uploading, it will appear in the Available Demodulator Versions list.

The screenshot displays the Adtec Digital Uploader interface. At the top, there's a navigation bar with tabs: Input, Video, Audio, CAS, VBI, System, Security, Upgrade (which is highlighted in blue), and Help. Below the navigation bar, there are two main sections:

- Installed Firmware Versions**: A table with one row showing "Version 1.01.04 (** current selection **)". To the right of the table are "Update", "Delete", "Restore" (in yellow), and "Current" buttons.
- Available Demodulator Firmware Versions**: A table with one row showing "Version 7044_AB_ntc6294_v1.36.adtec". To the right of the table are "Select" (in blue) and "Delete" buttons.

At the bottom of the interface is a window titled "Adtec Digital Uploader" with a progress bar. The progress bar shows "Completed" (blue), "% 14%", and "Status Uploading". Above the progress bar is a "Choose Files" button followed by the file path "7044_AB_ntc6294_v1.36.adtec.ntc.tgz".

The time required to update firmware varies on hardware model and should be accounted for during the maintenance windows.


Estimated Time required to update firmware:

LB Demod firmware update - ~6 minutes

ADV Demod firmware update - ~12 minutes

PRM Demod firmware update - ~26 minutes

Once the version is seen on the Upgrade -> Firmware tab, click 'SELECT' to start the upgrade process. A status bar will appear and will progress as the firmware update commences. When the firmware update is complete, reboot the unit and verify the firmware version again on the Upgrade -> Features Tab.



!!NOTE!! It is only recommended to update during a planned maintenance window. If a firmware upgrade fails for any reason, it is OK. Just try the upgrade again by clicking on the 'SELECT' button. The upgraded version can be verified by visiting the Upgrade -> Features tab after reboot. It is recommended to delete the file after a successful upgrade by clicking the 'DELETE' button.

Upgrading via FTP & Telnet

For those times when using the web user interface is not convenient, you can upload the firmware file via ftp and then extract and select into it via Telnet.

File Transfer Protocol (FTP)

FTP connections can be made to the Adtec device using any ftp client.

Host: <ipa of the unit>

Default Username: adtec

Default Password: none

Port: 21

You will want to drop the firmware file in the media/hd0/media folder.

Telnet (standard 23 port)

To connect to your unit using a terminal session you will need to set the IP address of the unit. See earlier instructions on setting the IP via the front panel.

Using a terminal window, complete the following:

Step	Action
1	Type 'telnet x.x.x.x' in a terminal window, without quotes, where x.x.x.x is the IP address of the unit.
2	Press <Enter>.
3	When prompted for a username, enter adtec.
4	When prompted for a password, enter none.

Once you see "User 'adtec' connected", the session is open and you may issue API commands to the unit.

To extract and select into the new firmware version you have uploaded, issue the following commands.

*.sysd version search

Copy the line designating the location of the new file.

Then type:

*.sysd version extract "copied path to new file"

Wait for the extraction to complete. Once complete, type the following command:

*.sysd version

Copy the line referencing the firmware version you wish to use and then issue the following command.

*.sysd version select "copied new firmware version"

Once you press enter, this will reboot your device into the new version.

In Field Feature Upgrades

Unit features can be upgraded in the field via the web user interface. Keys can either be temporary (feature will stop working after a set amount of time) or permanent (key is good for the life of the product). To purchase a permanent key, please provide your unit serial number and product ID from the Upgrade -> Features tab to your sales representative. If a temporary key is required, the Temporary ID will also be required.

Permanent Key Instructions

A permanent unlock key can be provided via email or verbally if internet access is not available. To enter the unlock key:

Step	Action
1	Click on the 'Input Key' button next to the desired feature.
2	Enter the supplied key into the pop-up dialog box and click OK.
3	The feature status should change from ' DISABLED ' to ' ENABLED '.
4	In some cases, a reboot of the unit may be required after a state change to ' ENABLED '. Reboot unit if enabled feature does not function.

The screenshot shows the RD-70 web interface. At the top, there's a navigation bar with links for Logs, Upload, Thumbnail, Logout, Input, Video, Audio, CAS, VBI, System, Security, Upgrade, and Help. The 'Features' tab is currently selected. Below the navigation bar, there's a 'Decoder Status' section and an 'RF Status' section for RF 1 and RF 2. In the 'Features' section, it shows Serial: 0201334025, Product ID: 7C62CB14447F191A, and Temporary ID: A764596B126298000018. A modal dialog box is open, prompting the user to enter a key to enable/disable RD-LB-32APSK. The dialog has an input field, an 'OK' button, and a 'Cancel' button. At the bottom of the page, there are buttons for DOLBY DEC, ENAB/ED, and NEVER.

Temporary Key Instructions

If a temporary key is provided, it will be in the form of an email attachment or file. Temporary keys are *not* entered through the 'Input Key' button. Instead, they are transferred to the unit through the use of the file transfer utility via the 'Upload' button. The 'Upload' button is found in the top right hand corner of the Web UI.

Step	Action
1	Download the temporary key file to your computer provided by your representative.
2	Click on the 'Upload' button in the top right hand corner of the Web UI.
3	Browse for the supplied 'ASC' file from the file browser pop-up and click 'Open'
4	The page should reload and feature status should change from ' DISABLED ' to ' ENABLED ' with a 'Days Left' count. This count determines how many days the key will function before returning to a ' DISABLED ' state.
5	In some cases, a reboot of the unit may be required. Reboot unit if enabled feature does not function.

The screenshot shows the Web UI interface with two main sections:

- Left Panel (Configuration):**
 - Current Status: LOCKED
 - Parameters:
 - Level: -48.2 dBm
 - S2: 28.7 dB
 - : 14.8 dB
 - : 32APSK_3/4
 - e: 1.144564 (Msym/s)
 - 1079.983 (MHz)
 - rate: 4.153656 (Mb/s)
 - Current Status: IDLE
 - Parameters:
 - Port: 0.0.0.0/0
 - Rate: N/A
 - Level: N/A / 0 (ms)
 - Protocol: UDP
 - Address: N/A
 - N/A
 - N/A
- Right Panel (Key Management):**

Slot ▾	ID	Name
2	BI20	PCA111 ver 2.0

Name	Status	Expires	Action
PdRD70	ENABLED	NEVER	Input Key
AUD-EXP	ENABLED	NEVER	Input Key
DOLBY-DEC	ENABLED	NEVER	Input Key
MP4-CHR-422D	ENABLED	NEVER	Input Key
MP4-CHR-420D	ENABLED	NEVER	Input Key
MP2-BASE-D	ENABLED	NEVER	Input Key
10BIT-D	ENABLED	NEVER	Input Key
1080P-DEC	ENABLED	NEVER	Input Key
RD-LB-16APSK	ENABLED	NEVER	Input Key
RD-LB-32APSK	ENABLED	35 days	Input Key
RD-LB-65MSYM	ENABLED	NEVER	Input Key
AAC-AUD-DEC	DISABLED	0 days	Input Key

Feature Key Descriptions

Base Unit Keys

PdRD7X - This is the product key to determine product type
MP2-BASE-D - Adds Mpeg2 4:2:0 and 4:2:2 decode capability
MP4-CHR-420D - Adds Mpeg4/AVC/H.264 4:2:0 decode capability
MP4-CHR-422D - Adds Mpeg4/AVC/H.264 4:2:2 decode capability
10BIT-D - Adds Mpeg4/AVC/H.264 10Bit decode capability
1080P-DEC - Adds 1080P50/59.94 decode capability
AUD-EXP - Adds support for 4 additional pairs of audio decoding
DOLBY-DEC - Adds support for Dolby Digital decoding (stereo downmix)
AAC-AUD-DEC - Adds support for AAC decoding (AAC-LC only at this time)
SVC-FLTR - Adds capability to filter services on ASI output

LB Demodulator keys

RD-LB-16APSK - Adds support for DVB-S2 16APSK demodulation
RD-LB-32APSK - Adds support for DVB-S2 32APSK demodulation
RD-LB-65MSYM - Adds support for >30 Msym/s demodulation

ADV and PRM Demodulator keys

Please contact your sales representative for available options.

Chapter 4 - Appendix

Appendix A - GNU General Public License

Version 2, June 1991 Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they

know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you". Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not

include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice. This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA

BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker. <signature of Ty Coon>, 1 April 1989 Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

Appendix B - Technical Specifications

Base Model (RD70-XX)

Inputs

DVB-ASI

Use: Input available for Decode or Pass to ASI outputs.

Standard: Asynchronous Serial Interface per EN500083-9

Input Rates: DVB-ASI 210Mb/s for free-to-air 188/204/208 Byte Transport streams (SPTS and MPTS).

If TSO (TS Out Decrypt) option is OFF and transport stream contains BISS encrypted programs, up to 164Mb/s at this time. If TSO option is ON and transport stream contain BISS encrypted programs (SPTS and MPTS), up to 120Mb/s. See TSO article in Chapter 3 for more information.

Connector: BNC (75 Ohm)

IP

Use: Input available for decode, but may also be used for control

Standard: MPEG 2 RTP v2 transport (RFC 3550), MPEG 2 UDP transport and RTP SMPTE 2022-1 2007 FEC

Input Rates: 1 - 210Mb/s (188 byte DVB packet size, 7 per IP packet)*

Connection speed: GigE (100/1000BaseT)

*Supported bandwidth decreases dependent on configuration. SMPTE 2022-1 supported up to 45Mb/s. 1 DVB Packet per IP Packet does not utilize the same data efficiency / throughput as 7. The amount of DVB packets per IP payload is a multicast transmitter configuration and is automatically detected by the receiver. To utilize full IP receive throughput, use of the GigE port with packetization of 7 DVB packets per IP packet is recommended.

The user has the ability to receive IP streams via the GigE or 10/100 management port. When receiving streams via the 10/100 management port, throughput is limited to wire speed.

Connector: 8 pin RJ45

DVB-S/S2 L-Band Demodulator (optional)

Use: Input available for decode.

Standard: DVBS & DVB-S2 QPSK/8PSK with 16APSK and 32APSK options available.

188/204/208 byte packet size

Connector: Two Female F connectors (75 Ohm)

Sync Input

Use: Auto-detects Bi-Level and Tri-level sync for Genlock, 3D and UltraHD applications.

Connector: BNC (75 Ohm)

Outputs

3G-SDI / HD-SDI / SD-SDI

Two banks (two mirrored SDI outputs per bank) of SDI Outputs from Decoder

Standard: Video & Audio SMPTE 259M - SD, SMPTE 292M - HD, SMPTE 424M - 3G

Up to 16 Channels of Embedded audio

SDI Ancillary support for Closed Captioning, AFD and Teletext
SDI Ancillary data and OSD overlay have unique configuration for each SDI bank
Connector: Three BNC (75 Ohm), One SFP
note*: 3G-SDI Outputs have selectable Level A and Level B Dual Link output control to retain interoperability with other third party 3G devices. The default mapping level is Level A.

CVBS

SD NTSC or PAL D1 Composite Video Output (downscaled from HD source)
Supports Closed Captioning and Teletext
Connector: BNC (75 Ohm)

DVB-ASI

Standard: Asynchronous Serial Interface per EN500083-9
ASI Mirrored from DVB-ASI Input, IP Input, or RF Input with purchase of optional tuner package. All streams are output as 188 byte packets.
Connector: Three BNC (75 Ohm)

AES Audio

Standard: AES3
8 pairs of decoded audio
Connector: Eight BNC (75 Ohm)

Analog Audio

Two balanced pairs via DB9 connector. (1 pair per DB9)
+18dBu nominal clipping level, -40 to +18dBu selectable.
Connector: Two DB9 (600 Ohm)

IP Output

Use: Output available for unicast/multicast transmit. TS input/output can share the same connector as required.
Standard: UDP, RTP and SMPTE 2022 COP3 FEC
Supports 1 to 7 TS packets per IP packet
Output TS Rate: 250 Kb/s to 120 Mb/s
Connection speed: GigE (10/100/1000 Auto-Negotiate)
Transmit capability: x4 simultaneous MPEG over IP transport streams
Connector: x1 RJ45 (Connector is shared for Input/Output)

Communications

COM2 Serial Port

Use: API Serial Communication Interface
Default Baud Configuration: 38,400bps 8 data bits 1 stop bit no parity
Connector: 8 pin RJ45

COM1 Serial Port

Use: Serial Port Used for Troubleshooting (Terminal)
Connector: 8 pin RJ45 (supplied with DB9 to RJ45 adapter)

Baud Configuration: 115,200 bps 8 data bits 1 stop bit no parity

Ethernet Port

Use: ethernet port used for network control, but can be used for IP receive/transmit

Format: Ethernet 10/100BaseT

Communication Methods: WebUI, SNMP, Telnet, XCP

Connector: 8 pin RJ45

DB9 Parallel Port

Use: DB9 parallel port used for custom triggering / integration

Connector: DB9 Male

GPIO Port

Use: not used as this time

Connector: DB9 Male

Video and Audio

Video Decode

MPEG-2 SD (ISO/IEC 13818-2) Decode:

Format: 480i59.94, 576i50

Profiles: MP@ML, SP@ML, 422P@ML

MPEG-2 HD (ISO/IEC 13818-2) Decode:

Format: 720p50, 720p59.94, 1080i50, 1080i59.94

Profiles: 422P@HL, MP@H14L, MP@HL, SP@H14L, SP@HL

MPEG-4 SD (ISO/IEC 14496-10) Decode:

Format: 480i59.94, 576i50

Profiles: Baseline, Main (support 8 bits only)

MPEG-4 HD (ISO/IEC 14496-10) Decode:

Format: 720p50, 720p59.94, 1080i50, 1080i59.94, 1080p50, 1080p59.94, 1080p25, 1080p29.97

Profiles: High, High422 (support 8 bit and 10 bit)

Max Level: 4.1-4.2 (CABAC:50Mb/s, CAVLC:150Mb/s)

Supported tools support Baseline except ASO, FMO

Audio Decode

MPEG 1 Layer 2 audio (8 pairs)

Dolby Digital AC3 stereo downmix (8 pairs) *requires feature key

Audio Pass-through

Supports up to two Dolby-E 16/20 bit, Dolby Digital AC3 16 bit, and/or Linear PCM 16/20/24 bit pass-through sessions. 24 bit input samples are truncated to 20 bits. Each SDI output contains all active pass-through sessions.

Physical and Operational

Physical / Environmental

1 RU - 18D X 19W X 1.65H

Weight – 9-14lbs. Dependent on RF Option

Power

Input Voltage: 100VAC - 240VAC 50/60Hz

Operational

- Ambient operating temperature: -20C to 40C.
- Ambient storage temperature: -30C to 80C.
- Non-condensing relative humidity range: 30% to 85%

Certification / Compliance

RoHS Compliant

Advanced Demodulator (ADV option)

note: Software keys are required to unlock full hardware support.

Modulation Scheme support: QPSK / 8PSK / 16APSK

DVB-S2 symbol rate range: 1 - 45Msym/s

DVB-S symbol rate range: 1 - 45Msym/s

frequency range: 950 - 2150MHz

min. input level: -70dBm

max. input level: -25dBm

Carrier acquisition Range: up to 7.5MHz

(if symbol rate < 5Msym/s: 1.5 x baudrate . if symbol rate > 5Msym/s: 7.5MHz)

LNB Power and Control:

11.5 - 14V (vertical polarisation)

16 - 19V (horizontal polarisation)

22kHz ± 4kHz (band selection according to universal LNB for ASTRA satellites)

L-Band Demodulator (LB option)

note: Software keys are required to unlock full hardware support.

RF Inputs: Dual RF inputs capable of simultaneous lock

EN 302 207 and EN 300 421 compliant for single and multi-stream

Modulation Scheme support: QPSK / 8PSK / 16APSK / 32APSK

Long and Short frame support

Supported Roll-off: 5%, 10%, 15%, 20%, 25%, 35%

Supported Code Rates:

DVB-S QPSK: 1/2, 3/5, 2/3, 3/4, 5/6, 7/8

DVB-S2 QPSK: 1/4, 1/3, 2/5, 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S2 8PSK: 3/5, 2/3, 3/4, 5/6, 8/9, 9/10

DVB-S2 16APSK: 2/3, 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S2 32APSK: 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S symbol rate range: Up to 62Msym/s*

DVB-S2 symbol rate range: 1 - 65Msym/s (QPSK / 8PSK / 16APSK / 32APSK)*

Automatic Modulation Coding and Symbol Rate detection capability

frequency range: 950 - 2150MHz

min. input level: -65dBm**

max. input level: -25dBm**

LNB Power and Control:

13V (vertical polarisation)

18V (horizontal polarisation)

22kHz (band selection according to universal LNB for ASTRA satellites)

**input level dependent on function of MODCOD and baudrate

* Maximum supported baud rate is dependent on both tuners active state. One must be disabled to achieve maximum symbol rate capabilities. View table below for symbol rate capabilities.

Modulation	Single Tuner (Msym/s)	Dual Tuner (Msym/s)
QPSK	65	65
8PSK	65	45
16APSK	65	33
32APSK	54	27

Premium Demodulator (PRM option)

note: Software keys are required to unlock full hardware support.

Modulation Scheme support: QPSK / 8PSK / 16APSK / 32APSK

Supported Roll-off: 5%, 10%, 15%, 20%, 25%, 35%

Supported Code Rates:

DVB-S QPSK: 1/2, 2/3, 3/4, 5/6, 6/7, 7/8

DVB-S 8PSK: 2/3, 5/6, 8/9

DVB-S/SNG 16QAM: 3/4, 7/8, (AUTO)

DVB-S2 QPSK: 1/4, 1/3, 2/5, 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S2 8PSK: 3/5, 2/3, 3/4, 5/6, 8/9, 9/10

DVB-S2 16APSK: 2/3, 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S2 32APSK: 3/4, 4/5, 5/6, 8/9, 9/10

DVB-S symbol rate range: 1 - 45 Mbaud

DVB-S2 symbol rate range: 0.256 - 45Mbaud (QPSK / 8PSK / 16APSK)

DVB-S2 symbol rate range 1 - 33Mbaud (32APSK, normal frames only)

frequency range: 950 - 2150MHz

min. input level: -70dBm

max. input level: -25dBm

Carrier acquisition Range: up to 7.5MHz

(if symbolrate < 5 Mbaud: 1.5 x baudrate . if symbol rate > 5 Mbaud: 7.5MHz)

LNB Power and Control:

11.5 - 14V (vertical polarisation)

16 - 19V (horizontal polarisation)

22kHz ± 4kHz (band selection according to universal LNB for ASTRA satellites)

Appendix C - Adtec Digital Support & Service

For Customer Service contact information, SLA Information, policies and more, please visit the support site at: <http://www.adtecdigital.com/support> .